



- 1 ROOF PANEL
- 2 PANEL CLIP WITH FASTENER. INSTALL 2 CLIPS AT EAVE TYPICAL
- 3 ONE LAYER OF 30 LB. FELT
- 4 PLYWOOD SHEATHING
- 5 10x1" PANCAKE HEAD WOOD SCREW, INSTALL 12" O.C. STAGGERED
- 6 CUT BACK VERTICAL LEGS AND FIELD FORM PANEL AROUND DRIP EDGE
- 7 DRIP EDGE, 4" END LAPS WITH CONT. CAULK AT LAPS
- 8 STRIP IN DRIP EDGE WITH ADDITIONAL COURSE OF 30 LB. FELT
- 9 Z-CLOSURE CLEAT. FIELD CUT TO FIT BETWEEN PANEL SEAMS
- 10 VERTICAL STANDING SEAM PANEL. ALIGN SEAMS WITH ROOF PANELS.
- 11 SILL TRIM, 4" END LAPS WITH CONT. CAULK AT LAPS