



- 1 ROOF PANEL
- 2 PANEL CLIP WITH FASTNER
- 3 ONE LAYER OF 30 LB. FELT
- 4 PLYWOOD SHEATHING
- 5 10x1" PANCAKE HEAD WOOD SCREW, INSTALL 12" O.C.
- 6 PANEL LEG OR FIELD FORM PANEL LEG (MIN. 1-1/4")
- 7 COUNTER FLASHING, 4" END LAPS WITH CONT. CAULK AT LAPS
- 8 ADDITIONAL COURSE OF 30 LB. FELT INSTALLED PARALLEL TO SIDEWALL
- 9 CONTINUOUS BEAD OF SEALANT BETWEEN FELT AND PANEL LEG
- 10 CONTINUOUS BEAD OF SEALANT BETWEEN PANEL LEG AND CONTINUOUS CLEAT
- 11 CONTINUOUS CLEAT FASTENED AT 12" ON CENTER